Instructions for use of the Heat/Humidity Chamber ("DFO/Ninhydrin Development Chamber")

- 1) Place item of evidence in the development chamber.
- 2) Turn applicable switches to the "on" position.
- 3) Observe the item while in the chamber, remove the item once results are visible on item and/or test print or a sufficient amount of time has elapsed.
- 4) Examine the item for results and, if needed, place the item back in the chamber for further processing.

Note: Make sure there is an adequate amount of purified water in the carboy before use.

Form Approved By:

Kaun W Momm